



QUICK REFERENCE GUIDE

Foreword

We are pleased to welcome you to the family of Perodua owners. As you know, the performance and durability of a vehicle depends, to a large extent, upon the way it is maintained and driven.

This Quick Reference Guide is a summary of basic vehicle operations. It contains brief description of fundamental operations so you can locate and use the vehicle's main equipment quickly and easily.

The Quick Reference Guide is not intended as a substitute for the vehicle Owner's Manual.

Full Owner's Manual can be downloaded from Perodua Official Website (www.perodua.com.my) or Perodua e-Owner's Manual page (<http://eownersmanual.perodua.com.my>).

For full awareness of your rights under the warranty granted and limitation set, please refer to the Warranty Booklet in Perodua e-Owner's Manual page.

We strongly encourage you to review the Owner's Manual and any other supplementary manuals so you will have better understanding of your vehicle's capabilities and limitations.


If you have any questions, feel free to contact your authorised Perodua Service Centre. We are ready to provide qualified service and assistance

PERODUA SALES SDN. BHD.

©2023 PERODUA SALES SDN. BHD.

All rights reserved. This material may not be produced or copied, in whole or in part, without the written permission of Perodua Sales Sdn. Bhd.

Scan the QR code to visit the
e-Owner's Manual Website



DISCLAIMER

The information in this manual is subject to change without notice. No part of this manual may be reproduced or transmitted in any form or by any means electronic or mechanical including photocopying, recording or information storage and retrieval systems for any purpose other than personal use without our written permission.

While every effort has been made to ensure that the information and contents in the manual are complete, accurate, up-to-date, reliable and non-misleading, we cannot be held responsible for mistakes, inaccuracies, or errors found in the manual. Nor is any liability assumed for damages resulting from the reliance and use of information contained herein. This manual is provided without any representation or warranties, express or implied.

PERODUA SALES SDN. BHD.

INDEX

OVERVIEW

| | |
|---|----|
| INSTRUMENT PANEL | 1 |
| INSTRUMENT CLUSTER | 2 |
| INDICATOR SYMBOL | 4 |
| KEY | 6 |
| PUSH START/STOP BUTTON* | 9 |
| FUEL TANK DOOR RELEASE AND CAP RELEASE | 11 |
| HOOD RELEASE | 11 |

FEATURES & OPERATIONS

| | |
|----------------------------------|----|
| CLOCK | 12 |
| SEATS | 13 |
| TILT STEERING* | 14 |
| SIDE VIEW MIRRORS | 15 |
| POWER WINDOWS | 15 |
| OPERATION OF CVT | 16 |
| PARKING BRAKE | 16 |
| LIGHTS, TURN SIGNALS AND WIPERS | 17 |
| ADVANCED SAFETY ASSIST (ASA)* | 20 |
| PRE-COLLISION WARNING* | 21 |
| PRE-COLLISION BRAKING* | 21 |
| PEDAL MISOPERATION CONTROL* | 22 |
| LANE DEPARTURE WARNING (LDW)* | 22 |
| LANE DEPARTURE PREVENTION (LDP)* | 23 |
| FRONT DEPARTURE ALERT* | 23 |
| IDLING STOP SYSTEM (eco IDLE)* | 24 |

FEATURES & OPERATIONS

(continued)

| | |
|---------------------------------------|----|
| HILL - START ASSIST SYSTEM | 26 |
| BLIND SPOT MONITOR (BSM)* | 27 |
| REAR CROSS TRAFFIC ALERT (RCTA)* | 28 |
| FRONT CORNER SENSOR & REAR SENSOR* | 29 |
| REVERSE CAMERA* | 29 |
| VSC & TRC SYSTEMS | 30 |
| EMERGENCY STOP SIGNAL | 31 |
| AIR CONDITIONING SYSTEM | 32 |
| AUDIO | 33 |
| BLUETOOTH OPERATION | 34 |
| STEERING WHEEL SWITCHES* | 35 |
| POWER SOCKET | 35 |


SAFETY & EMERGENCY

| | |
|--------------------------------|----|
| FLOOR MAT INSTALLATION | 36 |
| SEAT BELTS | 36 |
| FRONT SEAT BELT PRETENSIONERS | 36 |
| SRS AIRBAGS | 37 |
| TYPE OF CHILD RESTRAINT SYSTEM | 37 |
| DOOR LOCK | 38 |
| CHILD LOCK | 38 |
| IF VEHICLE BREAKS DOWN | 39 |
| TOOL, JACK AND TYRE LOCATION | 39 |

* : The equipment may vary according to the vehicle grade and options.

OVERVIEW

INSTRUMENT PANEL




- | | |
|-------------------------------------|---|
| ① Turn signal lever | ⑫ Engine start/stop button* |
| ② Headlight switch | ⑬ Parking brake |
| ③ Meters | ⑭ Power socket |
| ④ Wiper and washer switch | ⑮ Air conditioning* |
| ⑤ Audio* | ⑯ Advanced Safety Assist OFF switch* |
| ⑥ Hazard light switch | ⑰ VSC OFF switch |
| ⑦ SRS air bags for front passenger | ⑱ Headlight levelling switch |
| ⑧ Glove compartment | ⑲ Front corner sensor & rear sensor switch* |
| ⑨ Hood lock release lever | ⑳ eco IDLE OFF switch* |
| ⑩ SRS air bags for driver | ㉑ AHB switch* |
| ⑪ Tilt steering lock release lever* | ㉒ Central door lock switch |


* : The equipment may vary according to the vehicle grade and options.

INSTRUMENT CLUSTER

LCD MULTI-INFORMATION DISPLAY (WITHOUT TACHOMETER)*




LCD MULTI-INFORMATION DISPLAY (WITH TACHOMETER)*



* : The equipment may vary according to the vehicle grade and options.

TFT COLOUR MULTI-INFORMATION DISPLAY*


























- | | |
|-----------------------------|--|
| ① Speedometer | ⑧ Clock adjustment button |
| ② Multi-information display | ⑨ Service information reminder |
| ③ Fuel gauge | ⑩ Tachometer |
| ④ Shift position display | ⑪ TFT colour multi-information display |
| ⑤ Clock | ⑫ Content display |
| ⑥ ODO/Trip information | ⑬ Menu icons |
| ⑦ Display change button | ⑭ Driving assist display |

* : The equipment may vary according to the vehicle grade and options.

INDICATOR SYMBOL

For details, refer to "Warning lights and Indicators" in Section 2 Owner's Manual.

| | | | |
|--|---|---|---|
|  | Brake system warning light |  | Advanced Safety Assist OFF indicator* |
|  | Battery charge warning light |  | Lane Departure Warning activated light* |
|  | Low engine oil pressure warning light |  | Master warning light* |
|  | High engine coolant temperature warning light (red)/Low engine coolant temperature indicator (blue) |  | Sonar sensor indicator |
|  | Engine malfunction warning light |  | Slip indicator |
| CVT | CVT warning light |  | eco IDLE OFF indicator* |
|  | SRS airbags/pretensioner warning light |  | eco IDLE ready indicator* |
|  | ABS warning light |  | BSM OFF indicator* |
|  | Electric power steering warning light (red/yellow) |  | RCTA OFF indicator* |
|  | Key-free system warning light* |  | Brake override system warning light |
|  | AHB warning light (yellow)*/AHB activated light (green)* |  | Hands-free driving warning light* |
|  | Door ajar warning light |  | Low fuel warning light |

* : The equipment may vary according to the vehicle grade and options.



Driver & front passenger seat belts reminder light



Tail lights indicator



Rear seat passenger seat belts reminder light[※]



VSC OFF indicator



Parking brake warning light




TRC OFF indicator



Service information reminder



Eco driving indicator*



Turn signal indicator



Side-view mirrors indicator*



Headlights high beam indicator



Advanced Safety Assist operation indicator*



Security indicator



Lane recognition indicator*



Lane Departure Warning OFF indicator*



Power mode indicator*


If indicator does not turn off within a few seconds of starting engine, there may be a malfunction. Have the system checked by an authorised Perodua Service Centre.

※ : This light illuminates over the rear view mirror.


* : The equipment may vary according to the vehicle grade and options.

KEY


LOCKING OPERATION




UNLOCKING OPERATION





BACK DOOR UNLOCK OPERATION



PANIC ALARM BUTTON



EMERGENCY KEY*




Push the knob downwards to release the emergency key.


Use the emergency key if the Smart Key battery is weak or if the Smart Entry function does not operate properly.

* : The equipment may vary according to the vehicle grade and options.

LOCK / UNLOCK DOOR*



UNLOCK BACK DOOR*



Operating range may vary by surrounding conditions.


- (i) Key-free: Within 3 meter from centre of vehicle.
- (ii) Request switch: When the smart key is within approximately 80 cm from outer door handle.

* : The equipment may vary according to the vehicle grade and options.

DOOR AUTO LOCK AND UNLOCK FUNCTION

These functions designed to automatically lock or unlock all doors depending on the vehicle's situations.


Auto-lock functions



All doors locked when :

- Vehicle speed more than 20 km/h (initial setting).
- Shift lever moved from P while the engine is running.

Auto-unlock functions




All doors unlocked when :


- Engine switch is set to 'ACC' or 'OFF' after running at a speed of 20 km/h or more (initial setting).
- Shift lever is in P

PUSH START/STOP BUTTON*


PUSH START SYSTEM




TO START ENGINE



TO STOP ENGINE




TO CHANGE ENGINE SWITCH MODE




When brake pedal is not depressed, pressing the Push Start/Stop Button will change the engine mode.

* : The equipment may vary according to the vehicle grade and options.

SWITCHING ENGINE ON WHEN SMART KEY BATTERY IS WEAK




- 1 Move the shift lever to 'P' while depressing the brake pedal.




- 2 Touch the Smart Key to the engine switch until the indicator lights up in green and the alarm will deactivate.
- 3 Press the engine switch.


FUEL TANK DOOR RELEASE AND CAP RELEASE



Pull up the opener and open the fuel filler door.




Turn and open the cap slowly. To close after refill, turn the cap opposite until clicking sound can be heard.




During filling, place the cap on the hanger.


HOOD RELEASE



Pull the hood release lever.



Lifting the lever and open the hood.




Unlatch and insert the supporting rod into the slot.

FEATURES & OPERATIONS

CLOCK

LCD MULTI-INFORMATION DISPLAY*



- ① To set the hour (H).
- ② To set the minutes (M).
- ③ To set the minutes to '00'.
 - Press and hold button ① and ② together at the same time.

TFT COLOUR MULTI-INFORMATION DISPLAY*

Time and date setting



- ① Press $\leftarrow \rightarrow$ buttons to select \square (setting) menu.
- ② Press $\wedge \vee$ buttons to select 'Time and Date' and press ENTER button.
- ③ Time
 - For Hour/minutes, after \square displayed, press $\wedge \vee$ buttons to set minutes and hour, then press ENTER.
 - For 12H/24H will switch between '12H' (12 hour display) and '24H' (24 hour display) every time the ENTER button is pressed.
 - Regardless of 12H/24H settings, the clock will be displayed in a 24-hour format during adjustment.
- ④ Date
 - For 'Sort by Date', after \square is displayed, press the $\wedge \vee$ buttons to select the display order of the date and pressing the ENTER button again.
 - For "Day", "Month", and "Year", after \square displayed, press $\wedge \vee$ buttons to set day, month and year, then press ENTER.

* : The equipment may vary according to the vehicle grade and options.

SEATS


ADJUSTING THE SEATS

Front seats




- ① Adjusts seat positions.
- ② Adjusts seat back reclining positions.
- ③ Adjusts seat height. (Driver's seat only)


FOLDING THE SEAT BACK DOWN




- 1 Store seat belt buckle.



- 2 Insert the seat belt into the seat belt hanger.



- 3 Lower the headrest*.




- 4 Pull the lever and fold down the seat back.


* : The equipment may vary according to the vehicle grade and options.

ADJUSTING THE HEAD RESTRAINTS


Front seats



Rear seats*





Installing



Adjusting (front seats)




TILT STEERING*



* : The equipment may vary according to the vehicle grade and options.


SIDE VIEW MIRRORS

TO ADJUST



- ① Set the switch to left or right.
- ② Push the switch to adjust the mirror.

TO FOLD



Type A :


- ① To fold mirrors.
- ② To unfold mirrors.

Type B :


- ③ To fold and unfold mirrors by hand.

This component is enabled when the engine switch is in "ACC" or "ON" mode.

POWER WINDOWS



Passenger




One-touch opening (Driver's Window only)


- Opening the window: Push the switch down to completely open. To stop window partially, push the switch lightly in the opposite direction during opening.
- Closing the window: Pull the switch to close the window. The window will move as long as the switch is being operated.

OPERATION OF CVT


CVT TRANSMISSION



TO SELECT DRIVING MODE*




PARKING BRAKE




* : The equipment may vary according to the vehicle grade and options.

LIGHTS, TURN SIGNALS AND WIPERS

TURN SIGNAL LEVER




- ① Left turn.
- ② Lane change (left).
- ③ Lane change (right).
- ④ Right turn.





HEADLIGHT SWITCH

• Type 1




• Type 2




- ① Clearance lights, tail lights, license plate light.
- ② Lights on.
- ③ Lights off.
- ④ Lights on/off automatically.
- ⑤ High beam.
- ⑥ Headlight flasher.

FOLLOW ME HOME SYSTEM





- ① Switch 'OFF' engine switch.
- ② Pull lever towards self.
- ③ Release light switch in O or AUTO.

HEADLIGHT LEVELLING SWITCH



- ① Upward adjustment.
- ② Downward adjustment.

DAYTIME RUNNING LIGHT (DRL)*




Daytime running light operation condition:



- Engine is ON
- Headlight switch position in AUTO
- Parking brake release

AUTO HIGH BEAM (AHB)*

AHB helps to switch the headlights automatically into high beam or low beam depending on the surroundings brightness. (e.g. lights from street lamps, preceding vehicle or opposite directions vehicles.)



To activate, make sure to :

- 1 Switch 'ON' the engine switch.
- 2 Set lever to original position.
- 3 Set light switch to  (type 1),  or AUTO (type 2).
- 4 Turn 'ON' AHB switch.
- 5 Do not set front wiper to high speed operation.

Automatic high beam condition :


- Vehicle speed : 30 km/h or more.
- Vehicle's front area : Dark.
- No vehicle is coming in opposite direction.
- Street lamps in front : Dark.

Automatic low beam condition :

- Vehicle speed : 20 km/h or less.
- Vehicle's front area : Bright.
- There is vehicle coming in opposite direction.
- Street lamps in front : Bright.

* : The equipment may vary according to the vehicle grade and options.

FRONT WIPER AND WASHER




During intermittent (INT) operation, the interval becomes shorter as the driving speed rises.

ADVANCED SAFETY ASSIST (ASA)*


ASA is a system designed to support the driver's awareness, decision making and vehicle operation contributing to a safe driving experience.

STEREO CAMERA



- A stereo camera mounted in front of the inside rear view mirror which detect vehicle up to about 70 m (pedestrian up to 45 m) in front.
- The stereo camera will not operate properly if the wind shield view in front of the camera is obstructed by something, dirt, foggy, sticker etc.

ASA OFF SWITCH




ASA OFF indicator light will illuminate at the meter panel. Every time you start the engine by the engine switch operation, ASA function will return to ready state.

Refer to the Owner's Manual (Section 4) for additional information on operation, settings, adjustments, limitations and precautions before attempting to use it.

* : The equipment may vary according to the vehicle grade and options.

PRE-COLLISION WARNING*


Alert the driver when the stereo camera recognizes the high collision risk during day and night.



- When the system determines if there is a risk of collision, it will alerted and urged the driver to take evasive action by the buzzer and display.
- This function operates when the vehicle speed and speed difference between the front obstacles are :
4-120 km/h (vehicles, two-wheeled vehicles)
4-60 km/h (pedestrian)

PRE-COLLISION BRAKING*

Control the brakes to assist in avoiding collision as well as contributing in mitigating collision damage during day and night.



- If the system recognizes the front obstacles and determines that there is a high collision risk, it will change buzzer and control brakes.
- This function operates when the vehicle speed and speed difference between the front obstacles are :
4-120 km/h (vehicles, two-wheeled vehicles).
4-60 km/h (pedestrian).
- If the brake pedal is depressed under following conditions, it helps to decelerate with more braking force than normal :
30-120 km/h (vehicles, two-wheeled vehicles).
30-60 km/h (pedestrian).


- Continuously press the brake pedal to continue stop the vehicle because the vehicle will slowly start moving after 1.5 seconds.
- The operation cancelled if it determines low collision risk made by the driver such as pressing the brake pedal or operating the steering wheel.

Refer to the Owner's Manual (Section 4) for additional information on operation, settings, adjustments, limitations and precautions before attempting to use it.

* : The equipment may vary according to the vehicle grade and options.

PEDAL MISOPERATION CONTROL*

This function assist driver in avoiding collision by controlling engine output when the driver accidentally press the accelerator pedal.




The systems activates by following conditions :

- Stereo camera recognizes obstacle 4 m ahead.
- Pressing wrong pedal while driving slowly approximately 10 km/h or slower.


If the accelerator is pressed accidentally at approximately 4 km/h or less, the driver will be alerted by the buzzer and display.

LANE DEPARTURE WARNING (LDW)*

Alert the driver when there is a risk of the driver unintentionally depart from the vehicle lane.



Lane recognition indicator*



The system activates by following conditions :


- Engine switch is 'ON'.
- Vehicle speed : 60 km/h or more.
- Lane Departure Warning OFF indicator is off.
- Turn signal indicator off for 4 seconds after the turn signal indicator is turned off.
- Vehicle lane width approximately 3 m to 4 m.

Refer to the Owner's Manual (Section 4) for additional information on operation, settings, adjustments, limitations and precautions before attempting to use it.

* : The equipment may vary according to the vehicle grade and options

LANE DEPARTURE PREVENTION (LDP)*

Provides small steering force to the steering wheel to avoid the vehicle departing from the vehicle lane by alerts using buzzer and display.*




The diagram shows a car moving from a solid lane into a dashed lane, with a speech bubble indicating a warning. The system activates under the following conditions:

- Engine switch is 'ON'.
- Vehicle speed : 60 km/h or more.
- Lane departure warning OFF indicator is off.
- Turn signal indicator off for 1 second after the turn signal indicator is turned off.
- Vehicle lane width approximately 3 m to 4 m.

FRONT DEPARTURE ALERT*

Alerts the driver when the vehicle in front has moved.



The diagram shows a car following a dashed-line car. A speech bubble indicates a warning sound: "Pipipi". The warning will sound when your vehicle keep stopping although the preceding vehicle has already moved forward more than about 3 m away.

Shift position is other than **P** & **R** and distance between the stopped preceding vehicle and own vehicles is within about 10 m.

Refer to the Owner's Manual (Section 4) for additional information on operation, settings, adjustments, limitations and precautions before attempting to use it.


* : The equipment may vary according to the vehicle grade and options

IDLING STOP SYSTEM (eco IDLE)*





ECO

The 'eco IDLE' is a system that stop and restart the engine with the brake pedal without using the engine switch while the vehicle stops at a red traffic light or an intersection.

eco IDLE is ready



eco IDLE is OFF




- 1 When conditions for 'eco IDLE' mode are fulfilled during driving, the 'eco IDLE' ready indicator turns on in green (standby state).
- 2 While the shift lever is in D, depress the brake pedal and stop your vehicle for 'eco IDLE' mode. The indicator will remain on in green during 'eco IDLE' mode.
- 3 The engine restarts when foot is released from the brake pedal. The 'eco IDLE' ready indicator will turn off.
- 4 The 'eco IDLE' ready indicator turn on in green again after conditions for 'eco IDLE' mode are fulfilled.


Refer to the Owner's Manual (Section 4) for additional information on operation, settings, adjustments, limitations and precautions before attempting to use it.

* : The equipment may vary according to the vehicle grade and options

'eco IDLE' may not operate normally under the following conditions. Have the vehicle checked by an authorized Perodua Service Centre.



The interior light turns on when the driver's door is closed and does not turn on when the driver's door is opened.



Door ajar warning light turns on when the driver's door is closed and does not turn on when the driver's door is opened.




Seat belt reminder light flashes when driver's seatbelt is fastened, and/or does not flash when driver's seat belt is not fastened.


Refer to the Owner's Manual (Section 4) for additional information on operation, settings, adjustments, limitations and precautions before attempting to use it.

HILL - START ASSIST SYSTEM


Hill-Start Assist System helps to prevent the vehicle from rolling back when starting up again from a stopped position on an incline.



① Release the brake pedal slowly.




② Vehicle retains brake force for 2 seconds.




③ Accelerate to continue driving.

BLIND SPOT MONITOR (BSM)*


BSM overview : Assists driver when changing lanes.



BSM function: Detects the next vehicle running in the next lane using radar sensor and informs driver using side-view mirror indicator and buzzer.



BSM function effective range




Refer to the Owner's Manual (Section 4) for additional information on operation, settings, adjustments, limitations and precautions before attempting to use it.


* : The equipment may vary according to the vehicle grade and options.

REAR CROSS TRAFFIC ALERT (RCTA)*


RCTA overview : Assist driver when reversing.



RCTA function



RCTA function effective range



For fast vehicles, the buzzer will sound when the vehicle is further away.


| Approaching vehicle speed | ① Alert distance (estimate) |
|------------------------------|-----------------------------|
| Approximately 28 km/h (fast) | Approximately 20 m |
| Approximately 8 km/h (slow) | Approximately 5.5 m |

Refer to the Owner's Manual (Section 4) for additional information on operation, settings, adjustments, limitations and precautions before attempting to use it.


* : The equipment may vary according to the vehicle grade and options.

FRONT CORNER SENSOR & REAR SENSOR*


SONAR LOCATIONS AND TYPES



USE AND OPERATION OF SENSORS



REVERSE CAMERA*



Any object under the bumper or near both ends of the bumper are out of the reverse camera display range.

* : The equipment may vary according to the vehicle grade and options.

VSC & TRC SYSTEMS


Vehicle Stability Control (VSC)

Keeps the vehicle stable during sudden turns or on slippery roads.

Traction Control (TRC)

Assists with keeping the stability of the vehicle when accelerating on slippery roads.

VSC & TRC OPERATION




- These situations may arise depending on road, tyre and weather conditions.
- The vehicle is more secure if it is equipped with ABS (Anti-lock Braking System) & EBD (Electronic Brake force Distribution.)




IMPORTANT:

Even when VSC & TRC are operation, there are limits to the systems' traction and stability control. Dangerous driving may still cause accidents.



EMERGENCY STOP SIGNAL

Emergency stop signal system reduces the risk of collision by automatically flashing the hazard lights when the brakes applied suddenly to alert the vehicle behind.



Emergency stop signal operating conditions :

- Hazard warning signal light is OFF.
- Vehicle speed is about more than 60 km/h.
- The system determines from the vehicle deceleration and the pressed brake pedal that involve in sudden braking or when ABS system is activated.


Driver is obliged for a safe driving and avoid unnecessary sudden braking.

AIR CONDITIONING SYSTEM

Make sure the ignition switch is ON to operates the air conditioner blower.


TURN ON AIR CONDITIONER

• Type 1



- ① Turn the dial manually to 1 to 4.


• Type 2



- ① Press to on blower.
- ② Press A/C to on air conditioner.


TEMPERATURE CONTROL

• Type 1



- ① Set the dial to increase level.
- ② Set the dial to decrease level.


• Type 2



- ① Press to increase level.
 - ② Press to decrease level.
- MAXCOOL will appear after pressing to the maximum/end.

SET MEMORY


• Type 2



- ① Set preferred setting of air conditioner by pressing M1 or M2 button.
- ② To replace memory, hold either button for 1.5 seconds.


AUDIO

(Type A)



Refer to the Owner's Manual (Section 5) for more details.

(Type B)



Refer to the Multimedia Manual for more detail.

- ① Power/Mode button
- ② Select/auto store button
- ③ Mute button
- ④ Equalizer/clock button
- ⑤ Volume button
- ⑥ Bluetooth button
- ⑦ Voice Recognition Button

BLUETOOTH OPERATION

(Type A)

Bluetooth button




- ① Press and hold Bluetooth button for more than 2 seconds.
- ② LCD will display "PAIRING" and "Bluetooth" will flashing.
- ③ Confirm default passkey "0000" in mobile phone.
- ④ LCD will display "CONNECTED" and "Bluetooth" will stop flashing.

Refer to the Owner's Manual (Section 5) for more details.

(Type B)




- ① Select 'Bluetooth' button on main menu screen.
- ② Select 'Pairing' button to enter into pairing mode.
- ③ Use mobile phone to search for new bluetooth device mode.
- ④ Confirm the 6-digits passkey and press 'YES'.
- ⑤ Select 'OK' at mobile phone if the passkey is same.
- ⑥ LCD will display "CONNECTED" and ready to use.



Refer to the Multimedia Manual for more details.

STEERING WHEEL SWITCHES*



① Meter control switch

② Voice command for smartphone link**


③ Phone switch**

④ Audio remote control switches**

⑤ Driving mode switch*

*1: Refer to the Multimedia Manual for more details.



POWER SOCKET



* : The equipment may vary according to the vehicle grade and options.

SAFETY & EMERGENCY


FLOOR MAT INSTALLATION




Before driving, ensure that the floor mat is installed securely in the correct position.

SEAT BELTS


Fasten



Unfasten




FRONT SEAT BELT PRETENSIONERS



- Actuated when subjected to a strong impact from the front.
- Seat belt will instantly retract to secure the upper body of occupant.

SRS AIRBAGS



- ① SRS driver airbags/front passenger airbag (reduce impact of head and chest).
- ② SRS side airbags (reduce impact to the chest of front seat passenger)*.
- ③ SRS curtain shield airbags (reduce impact to the head for front and rear passengers)*.

TYPE OF CHILD RESTRAINT SYSTEM

Infants seats



Toddlers seats




Junior seats



- This vehicle is equipped with ISOFIX child restraint system seat.
- The child restraint system should be properly installed on the rear seat.


* : The equipment may vary according to the vehicle grade and options.

DOOR LOCK




- ① Lock the doors.
- ② Unlock the doors :
 - Driver door
Pull the inside handle lever.
 - Passengers door
Release locking knob and pull the inside handle lever.

CHILD LOCK




IF VEHICLE BREAKS DOWN



- ① Turn on the emergency flasher.
- ② Evacuate the occupants.
- ③ Place a triangle hazard sign (50 m or more from vehicle's rear).
- ④ Evacuate to safe place.

TOOL, JACK AND TYRE LOCATION



① Tool bag*

② Jack

③ Spare tyre

* Jack handle, wheel nut wrench, towing hook

Refer to the Owner's Manual (Section 7) for tyre changing and jack positioning procedure.

The following Wireless Communication products in this vehicle is certified (Type Approved) by SIRIM under Communication and Multimedia Act 1998



Immobilizer equipment (body ECU)



Keyless entry systems / immobilizer
(smartkey transmitter)

Blind spot monitor systems



PERODUA

Building Cars People First